


IXIO-ST INDUSTRIAL



Safety sensor
for industrial doors
(US Version)

DESCRIPTION




- | | | | |
|----|------------------------------|----|-----------------------------------|
| 1. | LCD | 5. | main connector |
| 2. | AIR-curtain width adjustment | 6. | main adjustment knob |
| 3. | AIR-lenses | 7. | AIR-curtain angle adjustment knob |
| 4. | cover | | |


ACCESSORIES




10IMB: Mounting Bracket




10ICA: Ceiling Adapter



10WRC: Clear Rain Cover




35.1286: Black Cover
35.1302: White Cover
35.1303: Silver Cover





CDA: Curved door accessory

1 MOUNTING & WIRING



12-24 V AC, 50/60 Hz
12-35 V DC
Max 2.5 W



TIP!
Mounting and wiring are compatible with the Wizard.

* Output status when sensor is operational

** SEE APPLICATION NOTES OR CONTACT BEA FOR TECHNICAL SUPPORT


Sensor connectivity (power and relays) must utilize only the supplied harness.
Sensor power must be supplied from a Class 2 supply source limited to 15 W.
Sensor is intended to be monitored for proper operation by the door operator or system.

Harness shall be routed separated from any Mains or non-Class 2 voltage cable for correct operation or shall be rated for the Mains voltage, and suitable protection and routing means shall be used according to National and Local Codes to prevent damage to the harness.


2 SAFETY ZONE




ANGLE



Activate the visible spots.*




If necessary, adjust the AIR-curtain angle (from -7° to 4°, default 0°).



* Visibility depends on external conditions
** The distance between the inner curtain of the inside door sensor and the inner curtain of the outside door sensor should always be smaller than 8 inches.

WIDTH



The arrow position determines the width of the detection field.



TIP!
Always remember to also adjust the width via the LCD or remote control (see p. 5)

Always verify the actual detection field width with this user's guide and not the Spotfinder, which detects the whole emitted field.

Mounting height	Detection width
6.6 ft	6.6 ft
7.2 ft	7.2 ft
8.2 ft	8.2 ft
9.8 ft	9.8 ft
11.5 ft	11.5 ft

The size of the detection field varies according to the mounting height of the sensor.
The full door width must be covered.

4 SETTINGS

Adjust the sensor by LCD or remote control (see p. 4 and 5)



5 SETUP



STEP OUT OF THE INFRARED FIELD!



SETUP 1 (QUICK)

reference picture



SETUP 2 (ASSISTED)


test of full door cycle +
reference picture



IMPORTANT! Walk test the proper operation of the installation before leaving the premises.

HOW TO USE THE LCD?

DISPLAY DURING NORMAL OPERATION



Activation Safety



Negative display = active output




To adjust contrast, push and turn the grey button simultaneously.

During normal operation only.

FACTORY VALUE VS. SAVED VALUE



displayed value = factory value



displayed value = saved value

NAVIGATING IN MENUS



Push to enter the LCD-menu



Enter password if necessary

Not during the first minute after power-on of the sensor.



Select your language before entering the first LCD-menu.

Available for the first 30 seconds after power-on of the sensor.



Scroll menu items




Select **Back** to return to previous menu or display.



Select **More** to go to next level:
- basic settings
- all settings
- diagnostics

CHANGING A VALUE



SCROLL MENU UP-DOWN



PUSH TO SELECT PARAMETER



current value is displayed



SCROLL VALUES UP-DOWN



more values are displayed






PUSH TO SAVE NEW VALUE



new value is displayed

CHANGING A ZIP CODE *



Validate the last digit in order to activate the new ZIP code:

- v = valid ZIP code, values will be changed accordingly
- x = invalid ZIP code, no values will be changed
- v/x = valid ZIP code, but from a different product. Only available values will be changed.

VALUE CHECK WITH REMOTE CONTROL



Pressing a parameter symbol on your remote control, displays the saved value directly on the LCD-screen. Do not unlock first.

* SEE APPLICATION NOTES OR CONTACT BEA FOR TECHNICAL SUPPORT

OVERVIEW OF SETTINGS



	0	1	2	3	4	5	6	7	8	9		
BASIC												
Back												
More												
AIR: WIDTH	[Icon]		[Icon]				[Icon]		[Icon]		Always additionally adjust the arrow position on the sensor with a screwdriver.	
AIR: OUTPUT *		NO NC	NC NO	NC NC	NO NO						NO: normally open NC: normally closed	
TEST *	off	on										[Icon]
More Back												
Back												
More												
AIR: IMMUNITY		normal	enhanced				mode B					[Icon]
AIR: WIDTH	[Icon]		[Icon]				[Icon]		[Icon]		Always remember to also adjust the arrow position on the sensor with a screwdriver.	
AIR: NUMBER	service mode	1	2	Service Mode = no IR detection during 15 minutes (maintenance).							[Icon]	
AIR: PRESTIME			30 s	1 min	2 min	5 min	10 min	20 min	60 min	∞	[Icon]	
AIR: FREQ		A	B	Sensors mounted close to each other should have a different frequency.							[Icon]	
AIR: OUTPUT *		NO NC	NC NO	NC NC	NO NO						NO: normally open NC: normally closed	
TEST *	off	on										[Icon]
REDIRECTION	motion	motion or presence	activation output is active in case of:					0 motion detection	1 motion or presence detection			[Icon]
FACTORYRST	restore to factory values										[Icon]	
ALL												
Back												
More												
DIAGNOSTICS												
Back												
More												
ZIP												
ID #	all parameter settings in zipped format unique ID-number											
CONFIG P/N	configuration part number											
SOFT P/N	software part number											
ERROR LOG	the last 10 errors, time since last error											
AIR: SPOTVIEW	view of spot(s) that trigger detection											
AIR: C1 ENERG	signal amplitude received on curtain 1											
AIR: C2 ENERG	signal amplitude received on curtain 2											
POWERSUPPLY	supply voltage at power connector											
OPERATINGTIME	power duration since first startup											
RESET LOG	delete all saved errors											
RC PASSWORD	password for remote control login											
ADMIN	enter code to access admin mode											
BACK												

* SEE APPLICATION NOTES OR CONTACT BEA FOR TECHNICAL SUPPORT



E1	 <p>The ORANGE LED flashes 1 x.</p>	<p>The sensor signals an internal fault.</p>	<ol style="list-style-type: none"> 1 Cycle power supply. 2 If orange LED flashes again, replace sensor.
E2	 <p>The ORANGE LED flashes 2 x.</p>	<p>The power supply voltage is too low or too high.</p>	<ol style="list-style-type: none"> 1 Check power supply (in the diagnostics menu of the LCD). 2 Check wiring.
E4	 <p>The ORANGE LED flashes 4 x.</p>	<p>The sensor does not receive enough AIR-energy.</p>	<ol style="list-style-type: none"> 1 Check the angle and width setting of the AIR-curtains. 2 Increase AIR-immunity filter to value 2 (enhanced).
E5	 <p>The ORANGE LED flashes 5 x.</p>	<p>The sensor receives too much AIR-energy.</p>	<ol style="list-style-type: none"> 1 Check the angle of the AIR-curtains. 2 Decrease the AIR immunity filter to value 1 (normal).
E8	 <p>The ORANGE LED flashes 8 x.</p>	<p>The AIR power emitter is faulty.</p>	<ol style="list-style-type: none"> 1 Relearn AIR. 2 Replace sensor.
	 <p>The ORANGE LED is on.</p>	<p>The sensor encounters a memory problem.</p>	<ol style="list-style-type: none"> 1 Cycle power supply. 2 If orange LED turns on again, replace sensor.
	 <p>The RED LED flashes quickly after an assisted setup.</p>	<p>The sensor sees the door during the assisted setup.</p>	<ol style="list-style-type: none"> 1 Check the angle of the AIR-curtains. 2 Launch a new assisted setup. <i>Attention: Do not stand in the detection field!</i>
	 <p>The RED LED flashes sporadically.</p>	<p>The sensor vibrates.</p> <p>The sensor sees the door.</p> <p>The sensor is disturbed by external conditions.</p>	<ol style="list-style-type: none"> 1 Check if the sensor is mounted firmly. 2 Check position of cable and cover. 1 Launch an assisted setup and adjust the AIR angle. 1 Increase the AIR-immunity filter to value 2 (enhanced).
	 <p>The LED and the LCD-display are off.</p> <p>The reaction of the door does not correspond to the LED-signal.</p>		<ol style="list-style-type: none"> 1 Cycle power supply. 2 Check wiring. 1 Check output configuration setting. 2 Check wiring.
	<p>The LCD or remote control does not react.</p>	<p>The sensor is protected by a password</p>	<ol style="list-style-type: none"> 1 Enter the correct password. To access the sensor without a password, cycle power. Sensor may be accessed for 1 minute.



Download the BEA DECODER app for a quick overview of settings



LED-SIGNAL




Motion detection



Presence detection




LED flashes



LED flashes x times



LED flashes red-green



LED flashes quickly




LED is off


INSTALLATION



Avoid extreme vibrations.



Do not cover the sensor.




Avoid moving objects and light sources in the detection field.



Avoid highly reflective objects in the infrared field.

MAINTENANCE




It is recommended to clean the optical parts at least once a year or more if required due to environmental conditions.



Do not use aggressive products to clean the optical parts.


SAFETY




The door control unit and the door cover profile must be correctly grounded.



Only trained and qualified personnel may install and setup the sensor.



Always test the proper operation of the installation before leaving the premises.




The warranty is invalid if unauthorized repairs are made or attempted by unauthorized personnel.



- The device should not be used for purposes other than its intended use. All other uses cannot be guaranteed by the manufacturer of the sensor.
- The installer of the door system is responsible for carrying out a risk assessment and installing the sensor and the door system in compliance with applicable national and international regulations and standards on door safety.
- The manufacturer of the sensor cannot be held responsible for incorrect installations or inappropriate adjustments of the sensor.
- The Sensor should be properly installed and adjusted and the proper functioning of the Sensor, when installed with an end product, as intended in UL 325 standard, shall be verified by the installer.

TECHNICAL SPECIFICATIONS

Supply voltage:	12 V - 24 V AC, 50/60 Hz; 12 V - 30 V DC (15 W Class II)
Power consumption:	< 2.5 W
Mounting height:	6.5 ft to 11.5 ft (local regulations may have an impact on the acceptable mounting height)
Temperature range:	Sensor: -31°F to +131°F LCD: 14°F to +131°F 0-95% relative humidity, non condensing
Degree of protection:	IP54
Applicable directives:	R&TTE 1999/5/EC; EMC 2004/108/EC; MD 2006/42/EC; RoHS 2002/95/EC
Detection mode:	 Presence Typical response time: < 200 ms (max. 500 ms)
Technology:	Active infrared with background analysis Spot: 5 cm x 5 cm (typ) Number of spots: max. 24 per curtain Number of curtains: 2
Output:	Solid-state-relay (potential and polarity free) Max. contact current: 400 mA Max. contact voltage: 42 V AC/DC Automatic Holdtime: 0.3 or 1 s
Test input *:	Sensitivity: Low: < 1 V; High: > 10 V (max. 30 V) Response time on test request: typical: < 5 ms

Specifications are subject to changes without prior notice.
All values measured in specific conditions.

* SEE APPLICATION NOTES OR CONTACT BEA FOR TECHNICAL SUPPORT

FCC

BEA Inc.

G9B

This device can be expected to comply with Part 15 of the FCC Rules provided it is assembled in exact accordance with the instructions provided with this kit. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

ANSI / AAADM

ANSI / AAADM Compliance *American Association of Automatic Door Manufacturers*

Upon completion of the installation or service work, at a minimum, perform a daily safety check in accordance with the minimum inspection guidelines provided by AAADM. Provide each equipment owner with an owner's manual that includes a daily safety checklist and contains, at a minimum, the information recommended by AAADM. Offer an information session with the equipment owner explaining how to perform daily inspections and point out the location of power/operation switches to disable the equipment if a compliance issue is noted. The equipment should be inspected annually in accordance with the minimum inspection guidelines. A safety check that includes, at a minimum, the items listed on the safety information label must be performed during each service call. If you are not an AAADM certified inspector, BEA strongly recommends you have an AAADM certified inspector perform an AAADM inspection and place a valid inspection sticker below the safety information label prior to putting the equipment into operation.

CONTACT

24/7 Technical Support:
1-800-407-4545

Customer Service:
1-800-523-2462

General Technical Questions:
Tech_Services@beainc.com

Technical Documentation:
www.beasensors.com

